

Impact Warning



What is Impact Warning?

Transmon's standalone iTEch Impact Warning device enhances site safety and operator accountability by raising awareness of an excessive impact.

The 3-Axis sensor is positioned on the vehicle's main chassis to monitor adverse acceleration/deceleration events, events above the programmed thresholds are logged. Output signals from the unit can be used to activate visual and acoustic warnings. Reset protection is incorporated whereby only authorised managers/supervisors are able to deactivate the alerts.


What's included:

- Impact sensor
- Diagnostic software
- Installation instructions
- Blue beacon, reset switch



Features:

- Voltage range: 8-60Vdc
- Management Reset Key
- Two configurable outputs
- Robust design, easy to install
- Environment protection: IP67, -10°C to +80°C
- 3-axis sensing with independent settings for X,Y,Z
- Programmable G-force and Duration-time thresholds
- Compatible with IC and Battery powered forklifts and vehicles
- Optional post incident Creep Speed reduction (requires a Transmon Speed Limiter)



Benefits to you:

- Increased site safety
- Reduced damage costs

Email: sales@transmon.co.uk or Call 0116 260 4200 for more information



Transmon Engineering Ltd
MATERIAL HANDLING & FLEET MANAGEMENT SPECIALISTS



www.transmon.co.uk

2a The Half Croft, Syston, Leicester, LE7 1LD